Revised on **2015.4.15** 



## **STABIO**<sup>TM</sup>

# Bio-based aliphatic polyisocyanate and its hardener for coating and adhesive

# Coating & Engineering Materials Div., Polyurethane Business Sector Mitsui Chemicals Inc.

Shiodome City Center 1-5-2, Higashi-Shimbashi, Minato-ku, Tokyo 105-7122, Japan TEL:+81-3-6253-3528

# 1. Concept of STABiO™




## High performance bio-based aliphatic polyisocyanate for polyurethane(PU) coating and adhesive


Features	Benefits -> Improve point	Compare with HDI
High Reactivity	<ul> <li>Short curing period</li> <li>Low drying temperature</li> <li>&gt; CO2 emission</li> <li>&gt; Environmental load</li> <li>&gt; Production cost</li> </ul>	ca.1.5-2 times high reactivity
High Isocyanate Content (NCO%)	<ul> <li>High performance PU</li> <li>Chemical resistance</li> <li>Abrasion resistance</li> <li>Decrease hardener amount</li> <li>Weather resistance</li> </ul>	ca.1.2 times Solvent Resistance ca.10% low amount
Low Viscosity	<ul> <li>High solid content</li> <li>&gt; Environmental load</li> <li>Superior smoothness</li> <li>-&gt; Appearance of coating film</li> </ul>	ca.20% low viscosity
Aliphatic non-symmetric structure	<ul><li>- High transparency</li><li>- Good weather resistance</li><li>-&gt; Appearance of coating film</li></ul>	High
Biomass	- Sustainable development	70% vs 0%

## 2. Polyisocyanate and Hardener





# Pentane-1,5-diisocyanate (STABiO<sup>TM</sup> PDI<sup>TM</sup>)



**STABiO<sup>TM</sup> Hardener** 

# 3. Advantage of STABiO<sup>TM</sup> PDI<sup>TM</sup>



Features of STABiO <sup>TM</sup> PDI <sup>TM</sup>			
High Reactivity	100		
High NCO %	54.5		
High biomass%	71 <sup>1)</sup>		

### 4. STABiO™ Harndener



#### 4-1. Characteristics

High NCO% and Low viscosity with High biomass%.

	PDI based		HDI based
	STABiO™ D-370N	STABiO <sup>™</sup> D-376N	TAKENATE™ D-170N
Solid %	100	100	100
NCO%	25	24	21
Viscosity mPa.s/25°C	2,000	900	2,600
Biomass%	70	67	0

### 4-2. Polyurethane properties

Superior chemical/solvent resistance and high hardness at small amount of hardener.

		PDI based		HDI based
		STABiO™ D-370N	STABiO™ D-376N	TAKENATE™ D-170N
Polyol/Hardener(w/w)		69/31	69/31	66/34
Reduction ratio over HDI		11%	8%	00/34
Hardness	Pencil Hardness	НВ	В	В
Chemical Resistance	Methanol Rubbing /times to break	1200	1000	1000

Polyol : Acryl base OHV 150mgKOH/g $T_{\rm g}$ =30°C, NV=50% Index:[NCO]/[OH]=1.0

Cure: 60°C-30min + 7days at 23°C50%RH






- Good hardness development at same potlife with HDI system
- Shorter the aging time by 25% than HDI based system

	STABiO™ D-370N	STABiO™ D-376N	HDI based TAKENATE™ D-170N
Workable time 1)	21hr	25hr	28hr

Aging time at 40cycles pendulum hardness, which remains no fingerprint after touching.



Acrylic Polyol, non-styrene type OLESTER<sup>TM</sup> (NV=50, OHV=150mgKOH/g,  $T_q$ =30°C)

Index:[NCO]/[OH]=1.0 Test plate: Steel (JIS-G3141)

Catalyst: DBTDL add to 6 hours pot life at room temperature Film thickness: 40µm, Baking: 60°C30min Aging: 23°C50%R.H.

Measurement: Pendulum Damping test, Koenig type

# 5. Properties of Bio-based Polyurethane

MITSUI CHEMICALS, INC.

Bio-based Polyol (TAKELAC™ U-27) Biomass 59%¹) Bio-based polyisocyanate STABiO<sup>™</sup> D-370N

Biomass:70%

**Bio-based Polyurethane Biomass 63%**<sup>1)</sup>

1)ASTM D6866 Method-B, 2)Butyl acetate

Item	Method		Film Property
Hardness	Pencil hardness glass plate	JIS K 5600	2B
	Martens hardness Steel Plate	ISO 14577	36 N/mm²
Flexural Durability	Cylindrical Mandrel Diameter 2mm, Tin Plate	JIS K 5600	Good
DuPont Impact	Steel Plate	JIS K 5600	1000g 1/5inch 20cm
Flexibility	Erichsen test Steel Plate	JIS K 5600	8.7 mm
Solvent Resistance	Rubbing Times to break Glass plate	Ethyl acetate	670
		Toluene	>1000
		MEK	300
Adhesion	Cross Cutting Steel Plate	JIS K 5600	100 /100



The information contained in this brochure is, to the best of our knowledge, accurate and reliable. But all suggestions are made without warranty, either express or implied. The values relevant to properties or the like of the product stated herein were obtained using laboratory test spiciness prepared in MISTUI CHEMICALS, INC.

laboratories and are not to be used as product specifications, nor assumed to be identical to values obtained on the finished product manufactured by our customers.

Nothing herein shall be construed as permission or as recommendation for uses which infringe valid patents or as extending a license under valid patents.

Because the conditions and methods of use on the part of our customers are beyond our control, MITSUI CHEMICALS, INC. disclaims any liability incurred in connection with the use of our products.

#### ■MITSUI CHEMICALS, INC.

Coating & Engineering Materials Division

1-5-2, Higashi-Shimbashi, Minato-ku, Tokyo 105-7122, Japan

TEL:+81-3-6253-3528 FAX:+81-3-6253-4271